

Using the Button Maker in the Library



1. Place the button components in the pickup die (left) and the crimp die (right).



2. Rotate the pickup die clockwise until it is underneath the upper die.



3. Pull the handle down, crimping the shell, graphic, and mylar in the upper die.



4. The button components are in the upper die. Raise the handle and rotate the crimp die counter-clockwise.



5. With the pin back still in the crimp die, pull the handle a second time.



6. Rotate the die clockwise to see your finished button.